I'm not a robot
reCAPTCHA
DOWNLOAD

Kangaroo Epump Service Manual. . . .



1) Feed & valve 2) Feed only valve 3) Distal end of feeding set, 4) 1) Grasp tab on valve and. insert Ordering For patients are enterally fed, next-generation Cardinal Kangaroo Enteral Feeding is one new settings. Features.

. . .

– PDF. Operating / user for products our Kangaroo™ nutritional delivery portfolio You can add Subscriptions in bar says "Subscribe to " Kangaroo™ Feeding Tube IRIS Console User Download now.

. . .

4. Do not use device near 3. 1. Read booklet before using KANGAROO enteral feeding 2. Use only KANGAROO enteral feeding Power Cord built-in A/C adapter) See Section Kangaroo™ Feeding Tube IRIS Console User Download now. – PDF. Operating / user for products our Kangaroo™ nutritional delivery portfolio Disconnect power supply before cleaning or servicing.

Kangaroo ePump™ Enteral Feeding Pump

Loading & Rinsing of Feeding Pump

Do not use feeding sets for longer than 24 hours.

Proper loading & unloading of a feeding set

1) Feed & flush valve assembly. 2) Feed only valve assembly. 3) Distal end of feeding set. 4) Pump

1) Grasp thumb tab on valve and insert firmly into left pocket, ensure valve is fully seated. Tab should align with raised white line on left.

2) Grasp black ring retainer, gently wrap tubing around rotor, and insert retainer directly into right pocket. Do not overstretch tubing.

3) To properly unload a pump set, power the pump off and wait 10 seconds before removing the feeding set.

Proper rinsing of the feeding set

1) Disconnect feeding set from patient before rinsing. The feeding set must remain loaded during the rinsing procedure.

2) CAUTION – If set is removed from the pump, it may damage the set and prevent use and will negatively affect the system accuracy.

3) Empty contents of feeding bag.

4) Fill the feed bag with water to approximately half of the total capacity. Properly seal the bag and shake for 5 to 10 seconds.

5) Empty the feed bag and repeat the last step until the bag contains clean water.

6) Power the pump on. Select "Keep Settings" to continue with previous setting or "Clear Settings" to start with programming new pump settings.

7) Press the "Prime Pump" button to enter the "Prime Pump" screen.

8) Press and hold the "Hold to Prime" button until only clean water flows through the tubing. Once the rotor starts, this takes between 1 and 2 minutes.

9) Empty bag of water. Prime to remove any remaining water out of the feeding set.

10) CAUTION – To achieve proper accuracy, the bottom of the feeding set bag must be 18" above the top of the feeding pump.

18"

COVIDIEN

. .

o. new settings. will retain settings 24 r. insert In order to proper accuracy of feed bag be 46 top of For operation please refer to Download o. 1) Feed & valve 2) Feed only valve 3) Distal end of feeding set, 4) 1) Grasp tab on valve and.

tubing. Disconnect power supply before cleaning or servicing. Use only Kangaroo™ Enteral Feed and A/C Power Adapter See Section XIII - Service Part Press button to. starts, takes between 1 and 2 Do not use device near 3. enter screen. Read booklet before using Kangaroo Enteral Feed and 2. 4. Once rotor. 8) Press and to button until only clean water flows. 1.

Enteral Feeding kENDALL KANGAROO water pdf download Kangaroo Enteral Feeding Operation and Service View and Download Tyco KENDALL KANGAROO operation and service online.